
Ultra-Drain Guard® Adjustable Frame Model
Installation and Maintenance Instructions

Part# 7112 / 8930 Ultra-Drain Guard, Adjustable Frame Model
Part# 8931 Ultra-Drain Guard, Adjustable Frame Model, 10-Pack
Part# 8932 Ultra-Drain Guard, Adjustable Frame Model Replacement Filter Fabric, 10-Pack

Installation:

The Ultra-Drain Guard, Framed Model is shipped with the frame in its smallest position.

1. Remove catch basin grating
2. Clean dirt and debris from grating ledge
3. Position the Ultra-Drain Guard on the lip of the catch basin and grasping opposite sides of the frame, stretch it as needed to fit the opening of the catch basin. Repeat this process for the other two sides of the frame as needed.
4. Reinstall grate. To insure maximum effectiveness, Drain Guard Frame should be secured (pinched) between grating and ledge.



Installation of Replacement Ultra-Drain Guard Insert (Part #8932):

1. Remove the Ultra-Drain Guard, Framed Model from the catch basin, and remove the insert from the frame by separating all of the hook and loop strips.
2. Dispose of the insert in accordance with applicable federal, state and local environmental laws and regulations.
3. Attach one replacement Ultra-Drain Guard Insert (Part# 8932) to the frame by securing all of the hook and loop strips.

Maintenance and Disposal:

1. The Ultra-Drain Guard filters are designed to be used for 3 to 6 months under normal conditions. Where heavy contamination is present the unit will have a reduced life expectancy. When the unit has collected about 6 inches of sediment it is recommended that it be replaced. The unit should also be replaced if free oil can be seen floating and is not being absorbed. The Ultra-Drain Guards should be inspected on a regular basis.
2. Dispose of unit in accordance with applicable federal, state and local environmental laws and regulations. The user is solely responsible for compliance with maintenance and disposal laws and regulations. The manufacturer or seller assumes no responsibility for proper or improper maintenance or disposal.