
ULTRATECH INTERNATIONAL, INC.


Parts List

	Part Description	Quantity
1	Base Support Unit	1
2	U-Bracket	1
3	Lever Arm	1
4	Lever Arm Extension	1
5	Lifting Arm	1
6	Handle	1
7	Grate Hooks (complete assembly - hooks, chains, connectors)	1
8	Hitch Pins	4
9	Cotter Pins	4




Ultra-Grate Lifter®
Assembly Instructions

Step 1: Insert U-Bracket into Base Support Unit.




Step 2: Attach the U-Bracket to the Lever Arm by inserting the hitch pin through the holes. Secure with cotter pin.




UltraTech International, Inc. · 11542 Davis Creek Court, Jacksonville, Florida 32256 USA
1-904-292-1611 · stormwaterproducts.com


Step 3: Attach the Lifting Arm to the Lever Arm by inserting the hitch pin through the holes. Secure with cotter pin.



Step 4: Attach the Lever Arm Extension to the Lever Arm by inserting the hitch pin through the holes. Secure with cotter pin.



Step 5: Insert handle into Lifting Arm Extension and secure with hitch pin and cotter pin.



Step 6: Attach the Grate Hooks to the end of the Lever Arm using threaded connector

